




HEAVY TRANSPORT

Kenworth Prime Movers

High Boy and Low Boy Floats



 Optional In Vehicle Monitoring System



Local support: we have fully equipped support bases in Port Moresby, NCD and Moro, Southern Highlands.



Rest assured: where operators are required, all our operators are fully qualified and licensed to operate the equipment.



Reliability: our entire rental fleet is maintained in-house and follows rigorous maintenance and inspection programs.

**We operate a fleet
of heavy
transportation
vehicles in PNG**

6x4 Drive Prime Movers
In Dash 2-Way Radio
Rotating Amber Light
Optional In-Vehicle Monitoring System
Experienced Field Operators



HIGH ARCTIC
Portion 2799 / 2870, Napanapa Road
Protocol Park, NCD, Port Moresby
+675-307-2000
www.higharctic.com

